





Gebrauchsanweisung
58 1367 (fr)
58 1368 (nl)
58 1369 (es)
58 1370 (pt)

Montageanweisung
52 4904
(de,en,fr,it,nl,da,sv,no
fi,es,pt,el,cs,pl,tr,ru)

Zubehoer:
HZ21004
Backblech Alu
HZ21101
Backblech emailiert
HZ21301
Universalpfanne
HZ21401
Kombirost
HZ22400
Einlegerost
HZ21710
Teleskopauszug
3-fach
HZ21700
Profi-Auszug
HZ24701
Deckel-f. Profipfanne
HZ22500
Grillblech
HZ9150
Glasbraeter

1) 01 4254





1) 48 2981
Set

Zubehoer:
HZ26000
Metallbraeter
HZ26001
Backform
Auslaufsicher

