






Ident-Nummern-Konstante
3740

Aufstellanweisungen
51 1191
(D,GB,F,I,NL,E)
51 1366
(D,F,I,S,DK)
Gebrauchsanweisungen
51 1182
(D,GB,F,I,NL)
51 1679
(D,F,I,S,DK)







BOSCH

T456-T456/00-D1
T456-T45635/00-GB1
T456-T45659/00-CH1

T456/01-D2
T45659/01-CH2

WASCHGERÄTE
Trockner

Ident.-Nummern-Konstante
3740

