

**BOSCH**

HES6726/01-D1, weiss
 HES6726/02-D2, weiss
 HES6726NL/01-NL1, weiss
 HES6726NL/02-NL2, weiss

HES6726/03-D3, weiss
 HES6726NL/03-NL3, weiss
 HES6726/04-D5, weiss
 HES6726NL/04-V01, weiss

HES6726/06-V02, weiss

HERDE
 Stand-Herde


Ident – Nummern – Konstante
 3740

Gebrauchsanweisung
 51 4803
 (D,GB,F,I,NL)

51 4465
 Kochbuch
 (D)
 51 4771
 Kochbuch
 (NL)

Zubehör:

HEZ 15BB
 Alu-Backblech
 HEZ 22BB
 Backblech emailliert
 HEZ 16BP
 Bratpfanne
 HEZ 16KP
 Universalpfanne
 HEZ 10SP
 Spritzschutzpfanne
 HMZ 21GB
 Glasbräter



**BOSCH**

HES6726/01-D1, weiss
HES6726/02-D2, weiss
HES6726NL/01-NL1, weiss
HES6726NL/02-NL2, weiss


HES6726/03-D3, weiss
HES6726NL/03-NL3, weiss
HES6726/04-D5, weiss
HES6726NL/04-V01, weiss

HES6726/06-V02, weiss

HERDE
Stand-Herde

Ident - Nummern - Konstante
3740

1) 08 7963



**BOSCH**


HES6726/01-D1, weiss
 HES6726/02-D2, weiss
 HES6726NL/01-NL1, weiss
 HES6726NL/02-NL2, weiss

HES6726/03-D3, weiss
 HES6726NL/03-NL3, weiss
 HES6726/04-D5, weiss
 HES6726NL/04-V01, weiss

HES6726/06-V02, weiss

HERDE
 Stand-Herde

Ident – Nummern – Konstante
 3740




**BOSCH**

HES6726/01-D1, weiss
 HES6726/02-D2, weiss
 HES6726NL/01-NL1, weiss
 HES6726NL/02-NL2, weiss

HES6726/03-D3, weiss
 HES6726NL/03-NL3, weiss
 HES6726/04-D5, weiss
 HES6726NL/04-V01, weiss

HES6726/06-V02, weiss

HERDE
 Stand-Herde



Ident - Nummern - Konstante
 3740

- 1) 02 9227
D1,D2,NL1,NL2
03 2750
D3,NL3,D4,V01,V02
K2
- 2) 05 4724
D1,D2,NL1,NL2
03 2407
D3,NL3,D4,V01,V02
K1,Start
- 3) 05 7412
- 4) 02 9469
M 10 A
- 5) 02 6011
F3,15 A
- 6) 05 8092
D1,D2,NL1,NL2
03 0812
D3,NL3,D4,V01,V02
06 9200
V01,V02
- 7) 03 1619
- 8) 05 9710
kompl.
D3,NL3,D4,V01,V02

**BOSCH**

HES6726/01-D1, weiss
HES6726/02-D2, weiss
HES6726NL/01-NL1, weiss
HES6726NL/02-NL2, weiss


HES6726/03-D3, weiss
HES6726NL/03-NL3, weiss
HES6726/04-D5, weiss
HES6726NL/04-V01, weiss

HES6726/06-V02, weiss

HERDE
Stand-Herde

Ident - Nummern - Konstante
3740

1) 04 4473



**BOSCH**

HES6726/01-D1, weiss
HES6726/02-D2, weiss
HES6726NL/01-NL1, weiss
HES6726NL/02-NL2, weiss

HES6726/03-D3, weiss
HES6726NL/03-NL3, weiss
HES6726/04-D5, weiss
HES6726NL/04-V01, weiss

HES6726/06-V02, weiss

HERDE
Stand-Herde

Ident - Nummern - Konstante
3740

1) 02 8633

2) 02 8634

08 7670
Glasschaber

