


HL5402-V01, weiss  
 HL54020/01-V02, weiss  
 HL54020/02-V03, weiss  
 HL54020/03-V04, weiss

HL54020/04-V05, weiss  
 HL54020DK/01-V06, weiss  
 HL54020DK/02-V07, weiss  
 HL54020DK/03-V08, weiss



Gebrauchsanweisung  
 51 3379  
 V01, V02, V03, V04, V05  
 (D, F, GB, I, NL)  
 51 4526  
 V06, V07, V08  
 (D, GB, F, I, NL, DK)  
 Tips und Rezepte  
 51 3804  
 V01, V02, V03, V04, V05  
 (D)  
 51 3559  
 V06, V07, V08  
 (DK)  
 Sonderzubehör  
 Blatt32

Zubehör:


Bratpfanne  
 HZ8040


Universalpfanne  
 HZ8059

Backblech Emaille  
 HZ8085

Backblech Alu  
 HZ8041

Spritzschutz  
 HZ8044





20 3805  
 V01  
 20 5071  
 V02, V03, V06, V07  
 20 5072  
 V04, V05, V08

1) 02 8633  
 2) 02 8634  
 3) 05 7021  
 V04, V05, V08

HL5402-V01, weiss  
 HL54020/01-V02, weiss  
 HL54020/02-V03, weiss  
 HL54020/03-V04, weiss

HL54020/04-V05, weiss  
 HL54020DK/01-V06, weiss  
 HL54020DK/02-V07, weiss  
 HL54020DK/03-V08, weiss

