






Aufstellanweisungen
51 1191
(D,GB,F,I,NL,E)
51 1366
(D,F,I,S,DK)

Gebrauchsanweisung
51 1976
(D,GB,F,I,NL)
51 1981
(D,F,I,DK,S)






**BOSCH**

T465-T465B/00-D1
T465-T46559B/00-DC1

WASCHGERÄTE
Trockner

Ident-Nummern-Konstante
3740



2) 02 1439

4) 08 7191
D1
08 5462
DC1