




Gebrauchsanweisung
51 5863
(GB)

1) 02 3404
RK1
02 7205
RK2

Zubehör:

Z2460X0
Topfträger

Z2400X0
Kleintopfring

Z1510X0
Bratenblech

Z1910X0
Brotbackstein

Z2600W0
Abstellplatte seith.


Z2900X0
Wärmeschutzleiste

Z2500X1
Sicherheits-
Gasschlauch


Z2221X1
Düsensatz Stadt-
/Erdgas

Z2300X0
Anschlußgarnitur
f. Flüssiggas


Z2231X1
Düsensatz Flüssiggas




- 1) 06 5963
- 2) 02 3271
- 3) 02 0561
- 4) 05 2759
- 5) 05 3182





- 1) 09 1046
- 2) 06 6026
- RK1
- 06 5959
- RK2





- 1) 02 2000
- 2) 02 5512
- 3) 02 5513
- 4) 02 5054
- 5) 02 3955
- 6) 02 7240
- 7) 08 3318











1) 14 0271
2) 11 2101