





**BOSCH**MCM2003/00-V01
MCM2205/01-V02KLEINE HAUSGERÄTE
KüchenmaschinenIdent – Nummern – Konstante
3740Gebrauchsanweisung
51 2456
(D,GB,F,I,NL,DK,N,
S,SF,P)1) 02 8829
2) 02 0665
3) 02 7247
4) 02 7248
5) 02 7249
6) 02 7256

Zubehör:

MCZ2ZP1
ZitruspresseMCZ2FW1
FleischwolfMCZ2RS1
Reibscheibe grobMCZ2PS1
Pommes-Frites-
ScheibeMCZ2GM1
Getreidemühle mit
Stahlmahlwerk




05 5879



08 6126

08 5280




08 3576

08 3577

08 0159
V01

08 4174




08 5415


05 7595

05 7594

08 4383



08 5417

08 5416
V01