


**BOSCH**

S712-SMS71224/01-I1


GESCHIRRSPÜLGERÄTE
StandgeräteIdent-Nummern-Konstante
3740

51 3033
EU1,I1
Gebrauchsanweisung
(D,GB,F,I,NL)
51 2277
Aufstellanleitung

- 1) 04 2085 Set
- 2) 04 2105 Set
- 3) 01 9177 Set
- 4) 02 5122
- 5) 02 5123
- 6) 02 2459
- 7) 02 5657 rot
- 8) 02 5658 grün
- 9) 02 5824
- 10) 11 7673 EU1,I1
11 8276 I2
- 11) 02 1237

**BOSCH**

S712-SMS71224/01-I1

GESCHIRRSPÜLGERÄTE
StandgeräteIdent.-Nummern-Konstante
37401) 08 0781
Set2) 02 5067
Set3) 01 9204
Set4) 20 2256
2300W

5) 05 1838

08 5572
kompl.

02 8923


02 7475

05 6228

11 7656
EU
11 8870
GB


Ident-Nummern-Konstante
3740

- 1) 10 4298
PVC Ø 5mm
2m
- 2) 08 6373
PVC Ø 8mm
2m
- 3) 11 2723
PVC Ø 12mm
2m
- 4) 11 2724
PVC Ø 8 mm
2m
- 5) 11 5388
kompl.
- 6) 03 0002
- 7) 02 9937



Ident-Nummern-Konstante
3740

- 1) 01 3861
- 2) 02 7386
- 3) 20 3079



**BOSCH**

S712-SMS71224/01-I1

GESCHIRRSPÜLGERÄTE
StandgeräteIdent-Nummern-Konstante
3740

1) 01 9202

2) 11 0668
Set3) 05 1287
Set

4) 20 2631

