




- 1) 08 7430
 (D,I)
 08 7429
 (F,NL)
 08 7431
 (DK,S)
 08 7433
 (E,GB)
 08 6685
 (TR,YU,GB,E)
 08 7432
 (N,SF)

Gebrauchsanweisungen:


- 51 3549
 (D,I,S,N,SF)
 51 3550
 (S,DK)
 51 3551
 (NL,F,E,GB)

Programmtabellen:

- 51 3552
 (D)
 51 3553
 (I,S,N,SF)
 51 3554
 (S,DK)
 51 3555
 (NL,F,E,GB)

Aufstellanweisungen:

- 51 3556
 (D,I,S,N,SF)
 51 3557
 (S,DK)
 51 3558
 (NL,F,E,GB)



1) 27 0442
 15 5272
 Triac-Motorleistung

