


Pos. Item Pos.	Ident-Nr. Ident-No N°d'ident	Bezeichnung	Designation Désignation
		Druckschriften	
	53 1032	Gebrauchsanweisung D/GB/F/E	instruction manual
	53 1033	Gebrauchsanweisung I/NL/S/DK	instruction manual
	53 5561	Schaltpläne und Platinen	schematic diagram
	53 5562	Service Manual	
		Zubehör	
	75 1529	AC-Kabel	AC-cable
	79 4021	Akku 4,8 V/1 Ah	
	75 8918	Akku 4,8 V/2,4 Ah	FZ168G4
	75 2521	AV-Verbindungskabel, cinch	AV-output cable cinch
	79 4612	Cinch-Skart Adapter	cinch-skart adaptor
	79 4240	DC-Kabel	DC-cable
	72 0064	Lithiumzelle CR2032	
	78 3177	Netzteil	AC-adaptor FZ157G4
	73 8076	S-VHS-Kabel	S-cable
	73 8884	Trageband	shoulder strap
	75 7000	VHS-Cassettenadapter	FZ163G4


Pos. Item Pos.	Ident-Nr. Ident-No N°d'ident	Bezeichnung	Designation Désignation
		Funktionseinheiten	
	79 3826	Antrieb	Drive P.C.B.
	79 4613	AV-out Buchsen	AV Jack P.C.B. P.C.B.
	75 9118	Camera Bedienteil	Camera Operation Unit P.C.B.
	75 8954	Camera Grundplatine	Camera Main P.C.B.
	79 4614	CCD	CCD Flexible Card P.C.B.
	79 4615	Eject	Eject P.C.B.
	79 4172	Interface	Interface P.C.B.
	79 4167	Mikrofon	Mic Unit P.C.B.
	79 4171	Netzteil	Power P.C.B.
	79 4617	S-Buchse	S-Jack P.C.B.
	79 4618	Start-Stop	S/S Power P.C.B.
	79 4174	Sucher	B/W E.V.F. P.C.B.
	79 4616	Sucher-Sensor	EVF Sensor Flex P.C.B.
	75 8953	VTR Grundplatine	VTR Main P.C.B.
	79 4173	Weibabgleich	AWT Sensor P.C.B.
		Diverse Bauteile	
J1001	79 4672	Akkuanschluss	Akku Jack
J1002	79 2386	Anschluss Lithiumzelle	Jack
J1501	79 3154	S-VHS, Edit Buchse	Jack S-VHS
J1501	79 3960	DC-Buchse	DC-Jack
J1502	79 4613	Jack	AV-out
J4301	79 3155	Mikrofonbuchse	Mic-Jack
TH701	79 1857	Thermistor	



Pos. Item Pos.	Ident-Nr. Ident-No N°d'ident	Bezeichnung	Designation Désignation
			
IC201	79 4164	VEFH38A	
IC202	79 4161	TC7SU04F	
IC203	79 4150	AN2018S	
IC204	79 4151	AN2034FAP	
IC301	79 4156	MN6576H	
IC302	79 4157	MN67321	
IC305	79 3098	MN65702H	
IC308	79 4155	MN1864002V8P	
IC309	79 3147	MN73512XWAS	
IC310	79 0762	M62352GP	
IC311	79 3833	X25040S-3C70	
IC313	79 0762	M62352GP	
IC314	79 3815	TC9074F	
IC401	79 4154	M52942AFP	
IC701	79 0404	TC4S584F	
IC702	79 4153	LB1830M	
IC703	79 3813	TB6512F	
IC705	73 9722	LM358DB	
IC706	73 9720	LM324DB	
IC707	73 9720	LM324DB	
IC801	79 1803	AN2515S	
IC1001	79 3803	BA9706K	
IC2001	79 3814	TB6513AF	
IC2002	79 0798	UN224	
IC2003	79 0798	UN224	
IC3001	79 3148	VEFH25D	
IC3002	79 3808	MN3851MS	
IC3003	79 1766	AN3298NSB	
IC3005	79 1769	BA7062F	
IC4001	79 1768	AN3998FAP	
IC4301	79 4619	UPC2356GS	
IC4501	79 1791	VEFH27B	
IC5001	79 4152	AN3352FHP	
IC6001	79 4158	MN6755240V8Q	
IC6002	79 1785	RH5RE38AA	
IC6003	79 1775	MN13821-Y	
IC6004	79 3089	BA6289F	
IC6005	79 5285	TC4S66F	

Pos. Item Pos.	Ident-Nr. Ident-No N°d'ident	Bezeichnung	Designation Désignation
			
IC6007	73 9723	LM393DB	
IC6008	79 4163	UPD74HC00G	
IC6013	79 8285	TC4S66F	
IC6015	79 0770	TC4W53F	
IC6016	79 0205	UPD74HC32G	
IC6181	73 9722	LM358DB	
IC6201	79 4620	UPD17401G553	
IC6202	79 0200	S8420KF	
IC6203	79 0771	TC7W04F	
IC8001	79 1790	VEFH26B	
IC8002	79 3102	TL8841F	
			
T801	79 4658	Zeilentrafo	Flyback transformer
T1001	79 4166	Transformator Netzteil	Power supply transformer
T1002	79 4177	Transformator Netzteil	Power supply transformer
T4001	79 4659	Löschoszillator	Erase osc.
			
VR801	73 8511	220 Ohm	
VR803	79 0817	5.6 MOhm	
VR804	79 0818	2.2 MOhm	
VR805	79 0816	10 KOhm	
VR3004	79 0211	5 KOhm	
VR3005	73 9871	2 KOhm	
VR3006	79 0816	10 KOhm	
VR3007	73 8455	50 KOhm	
VR3008	73 8523	500 Ohm	
VR4002	73 8455	50 KOhm	
VR4501	73 9871	2 KOhm	
VR6201	73 9872	100 KOhm	

Pos. Item Pos.	Ident-Nr. Ident-No N°d'ident	Bezeichnung	Designation Désignation
X201 X301 X302 X3801 X6001 X6002 X6201 X6202 X8001	79 4660 79 4661 79 4662 79 1928 79 0824 79 4663 79 0825 79 4664 73 9750	 12.875 MHz 12 MHz 10 MHz 4.43 MHz	
		Messwerkzeuge	Measurement tools
	34 0214 34 0260 34 0216 34 0217 34 0290 79 4668	H-Position Abgleich VHS-C Abgleichcassette Conv. Filter Conv. Filter Abgleichcomputer ROM22	H-Position Adjustment VHS-C alignmenttape C 12 C 2 E.V.R. Fixture
		Adapterkabel	Adaptor cables
	34 0189	5 Pin	Camera-EVR
	34 0320	22 Pin	Camera-Main-Camera Operation
	34 0293	18 Pin	Camera-Netzteil
	34 0371	18 Pin	Camera-VTR
	34 0199	24 Pin	Messkabel
	34 0326	9 Pin	VTR-A/C Kopf
	34 0377	10 Pin	VTR-AV-out
	34 0375	23 Pin	VTR-Cylinder
	34 0370	23 Pin	VTR-Drive
	34 0324	16 Pin	VTR-Mechanik
	34 0325	6 Pin	VTR-Mechanik
	34 0376	28 Pin	VTR-Netzteil



* = 79 3209 (5 pcs)

