










G 620 i - 0 730 301 002-SK,
G 620 i w - 0 730 301 003-SK.

Ident-Nummern-Konstante
3740




G 620 i - 0 730 301 509-EU, G 620 i-S - 0 730 301 518-EU
G 620 i w - 0 730 301 513-EU, G 620 i w-S - 0 730 301 519-EU, bis FD 6203, G 620 i - 0 730 301 528-GB.





G 620 i	- 0 730 301 002-SK,	G 620 i-S	- 0 730 301 518-EU,	G 620 i	- 0 730 301 528-GB.
G 620 i w	- 0 730 301 003-SK,	G 620 i w-S	- 0 730 301 519 bis FD 6203,		
G 620 i	- 0 730 301 509-EU,	G 620 i w-S	- 0 730 301 519 ab FD 6204,		
G 620 i w	- 0 730 301 513-EU,	G 620 i w	- 0 730 301 526-CH,		

Ident-Nummern-Konstante
3740



G 620 i	- 0 730 301 002-SK, G 620 i-S	- 0 730 301 518-EU,	G 620 i	- 0 730 301 528-GB.
G 620 i w	- 0 730 301 003-SK, G 620 i w-S	- 0 730 301 519 bis FD 6203,		
G 620 i	- 0 730 301 509-EU, G 620 i w-S	- 0 730 301 519 ab FD 6204,		
G 620 i w	- 0 730 301 513-EU, G 620 i w	- 0 730 301 526-CH,		

Ident-Nummern-Konstante
3740

