


**BOSCH**

ELEKTROHERD EH 43 S0 - 0 750 010 005
 EH 43 S - 0 750 010 006
 EH 44 S0 - 0 750 030 010

Ident-Nummern-Konstante
 3740



130460-1/1

* zu 0 750 010 005
 + zu 0 750 010 006
 ⊕ zu 0 750 030 010