




**BOSCH**


SMS 6112 – 0 730 101 639–DK1

GESCHIRRSPÜLGERÄTE
StandgeräteIdent-Nummern-Konstante
374051 2613
DK1
Gebrauchsanweisung
(DK)
51 2277
Aufstellanleitung

- 1) 04 2085
Set
- 2) 04 2105
Set
- 3) 01 9177
Set
- 4) 02 5122
- 5) 02 5123
- 6) 02 5657
rot
- 7) 02 5658
grün
- 8) 02 5824
- 9) 02 7950


Ident-Nummern-Konstante
3740





Ident-Nummern-Konstante
3740

1) 01 3861
2) 02 7386



**BOSCH**

SMS 6112 — 0 730 101 639—DK1

GESCHIRRSPÜLGERÄTE
StandgeräteIdent-Nummern-Konstante
3740