



**BOSCH**

SMS 6110 — 0 730 101 023—SK1

GESCHIRRSPÜLGERÄTE
StandgeräteIdent-Nummern-Konstante
3740

- 51 2261/00
SK1
Gebrauchsanweisung
(S,N,SF)
51 2277/00
Aufstellanleitung
1) 04 2085/04
Set
2) 04 2105/03
Set
3) 01 9177/02
Set
4) 02 5122/01/4
5) 02 5123/01/2
6) 02 5657/01
rot
7) 02 5658/01
grün
8) 02 5824/01/3
9) 02 5125/01/3
Taste hell
10) 02 5126/03/1
Taste dunkel
11) 08 2896/21
bis FD 6504
08 4237/21
ab FD 6505




Ident Nummern Konstante
3740

- 1) 11 1482/03
- 2) 01 9204/02
- Set
- 3) 05 1838/01
- bis FD 6504
- 4) 05 5117/01
- ab FD 6505


Ident Nummern Konstante
3740

1) 01 3861/01/5
2) 02 7386/02/2



**BOSCH**

SMS 6110 — D 730 101 023—SK1

GESCHIRRSPÜLGERÄTE
StandgeräteIdent-Nummern-Konstante
3740

- 1) 01 9202/01/4
 2) 11 0668/07
 Set
 3) 05 1287/03
 Set
 4) 20 1970/33
 EU1
 20 2631/33
 I1