




Mat. - Nr. - Konstante
3740

Gebrauchsanweisung
59 1154


- 1) 17 1312
- 2) 42 4340
- 3) 43 8723
- 4) 48 9131
- 5) 16 5552
- 6) 36 9906
- 7) 41 8169
- 8) 49 1665
- 9) 17 1508
- 10) 17 1565


Mat. - Nr. - Konstante
3740

1) 06 0083

2) 49 1361

3) 16 5557



Pos.	Danfoss		
	NLE13KK3		
1	14 3864		
2	18 1014		
3	49 1201		
4	16 3427		
5	49 1201		
6	17 1318		
7	17 1519		
8	16 5570		
9			
10			
11			
12			

TECHNISCHE DATEN/TECHNICAL DATA/TEKNIK BİLGİLER			
Verdichter/Compressor/Kompresör Typ/Type/Tip Förderleistung/Delivery/Verim/h Anlaufstrom/Starting current/Giris akimi Widerstand/Resistance/Rezistans Ha/ Hi/aux.	Danfoss NLE13KK3 6.4 12.9 18		
Temp.Reyler/Thermostat/Termostat Typ/Type/Tip Reglerstellung/Position/Termostat pozisyonu Schaltwerte/Actua kapama degerleri Valeurs de commutation/Termostat degeri (..abtaven' od)	Elektronisch ..ein/acma °C ..aus"/kapama ..alarm'		
Füllmenge/Fill. quantity/ Dolum miktarı	R134a	g	*
Anschlusswert/Comm. load/Giris gucu	W		*
Heizung/Heater/Rezistans Widerstand/Resistance/Direnc Leistung/Power/Guc	Ohm W	Verdampfer 160	Ablaufrinne 20
Ventilador/Blower/Vantilatör Widerstand/Resistance/Rezistans	Ohm	Verdampfer	
Magnetventil/Magnetic valve/Manyetik valf Widerstand/Resistance/Rezistans Spannung/Voltage/Gerilim	Ohm V		
Temp.Reyler/Thermostat/Termostat			

* Siehe Typenschild/Mamul etiketine bakiniz