





Gebrauchsanweisung
52 0008
(F, NL, GB, E)

Montageanweisung
51 8967
(F, NL, GB, E)

1) 16 1816
V01, V04
15 4716
V02, V05
15 4717
V03, V06

2) 16 2259
V01, V04
16 2556
V02, V05
16 2257
V03, V06

3) 16 2258
V01, V04
15 2539
V02, V05
16 2542
V03, V06



1) 26 3075

