





Gebrauchsanweisung
52 3849
(de,en,fr,nl,it,es,el)


Montageanleitung
51 7991
(de,fr,nl,it)

1) 02 5876


Zubehör:

Back- u. Bratrost-
engmaschig
Z1440X0
Back- u. Bratrost
geköpft
Z1430X0
Backblech Alu
Z1330X0
Backblech Email
Z1340X0
Bratenblech
Z1510X1
Brotbackstein
Z1910X0
Grilleinrichtung 2,7 KW
Z1130X0
Universalpfanne u.
Bratrost
Z1230X0
Auflaufform
Z1270X0





- 1) 15 4762
- 2) 15 4763
- 3) 16 7255
- V01
- 16 7262
- V02



1) 15 4779