

**BOSCH**

BBS232031 – 0 752 210 179-N1
 BBS232035 – 0 752 210 182-DK1
 BBS2320 – 0 752 210 186-NL1

BBS232046 – 0 752 210 188-NL2
 BBS232061 – 0 752 210 190-F1


BODENPFLEGEGERÄTE
 Bodestaubsauger

Ident – Nummern – Konstante
 3740

Gebrauchsanweisung

51 3879
 N1,DK1
 (D,DK,N,SF,S)
 51 3876
 NL1
 (NL)
 51 3878
 NL2
 (NL)
 51 2789
 F1
 (F)

1) 02 1519
 2) 05 5235
 3) 05 5239



**BOSCH**

BBS232031 – 0 752 210 179–N1
BBS232035 – 0 752 210 182–DK1
BBS2320 – 0 752 210 186–NL1

BBS232046 – 0 752 210 188–NL2
BBS232061 – 0 752 210 190–F1

BODENPFLEGEGERÄTE
Bodenstaubsauger

Ident – Nummern – Konstante
3740

1) 02 7593

Zubehör:
BBS 23..
BBS 232

