




1	01 1688/05/10	Linsenschraube (M 6 x 4)
2	01 1687/03/100	Dichtung, Fiber D = 10 mm, d = 6 mm, l = 0,8 mm
3	01 1686/05/20	Madenschraube (M 6 x 6)
5	01 1693/06/100	Fiberdichtung D = 21 mm, d = 16,7 mm, l = 1,5 mm
6	25 5114/03/10	Kegeldichtung D = 13 mm, d = 7 mm, l = 2 mm
7	25 5256/06/2	Kappe
8	25 5121/01/10 25 5373/04/20	Scheibe, Fiber für Ausf. Kuri D = 18,5 mm, d = 12 mm, l = 2 mm für Ausf. KS D = 26 mm, d = 21 mm, l = 1 mm
9	25 5255/06/2 25 5375/06/2	Kappe für Ausf. Kuri für Ausf. KS
10	01 1690/04/10 25 5321/10/10	O-Ring für Ausf. Kuri D = 16 mm, d = 12 mm, l = 2 mm für Ausf. KS D = 15,9 mm, d = 12,42 mm, l = 1,78 mm
11	25 5251/02/10 25 5374/06/10	Feder für Ausf. Kuri für Ausf. KS

12	25 5100/10 25 5102/10	Rohr für ZS 70 für ZS 71 s/AX 17 10
13	25 5210/05/2	Mutter (Überwurfmutter R 3/8", Bohrung 12,3 mm)
14	25 5118/02/10	Scheibe, Messing D = 14,8 mm, d = 7,2 mm, l = 0,8 mm
15	25 5156/02/10	Quetschdichtung D = 15 mm, d = 12 mm, l = 3 mm
16	25 1500/18 25 1510/20	Drosselstück 30 mm Länge 60 mm Länge

Ersatzteile zu ZS 3/AX 1030

