





Mat. - Nr. - Konstante
3740


Gebrauchsanweisung
58 7647

- 1) 17 1312
- 2) 42 4340
- 3) 43 8727
- 4) 48 9131
- 5) 16 5552
- 6) 43 5739
- 7) 41 8128
- 8) 43 5738
- 9) 43 6398
- 10) 49 0859
- 11) 17 1508
- 12) 17 1565
- 13) 49 1346
- 14) 42 2142



Mat. - Nr. - Konstante
3740

- 1) 43 5817
- 2) 43 6833
- 3) 43 6865
- 4) 49 1361
- 5) 49 0669
- 6) 49 0670
- 7) 17 1321
- 8) 43 6832
- 9) 43 5710
- 10) 35 4789



Pos.	Danfoss		
	NLE15KTK2		
1	14 2207		
2	18 1014		
3	35 4583		
4	16 3427		
5	49 1201		
6	17 1318		
7	17 1519		
8			
9			
10			
11			
12			

TECHNISCHE DATEN/TECHNICAL DATA/TEKNIK BİLGİLER				
Verdichter/Compressor/Kompresör Typ/Type/Tip Förderleistung/Delivery/Verim/h Anlaufstrom/Starting current/Giris akimi Widerstand/Resistance/Rezistans Ha/ Hi/aux.		Danfoss NLE15KTK		
Temp. Reyler/Thermostat/Termostat Typ/Type/Tip Reglerstellung/Position/Termostat pozisyonu Schaltwerte/Actma kapama degerleri Valeurs de commutation/Termostat degeri (...abtaven' od)		Elektronisch +4,5 +4,5 -13 -18		
Füllmenge/Fill. quantily/ Dolum miktarı		R600	g	
Anschlusswert/Comm. load/Giris gucu		W	230	
Heizung/Heater/Rezistans Widerstand/Resistance/Direnc Leistung/Power/Guc		Ω W	Verdampfer 267	Ablaufrinne 81 Klappe 4
Ventilador/Blower/Vantilatör Widerstand/Resistance/Rezistans		Ω		
Magnetventil/Magnetic valve/Manyetik valf Widerstand/Resistance/Rezistans Spannung/Voltage/Gerilim		Ω V		
Temp. Reyler/Thermostat/Termostat				

* Siehe Typenschild/Mamul etiketine bakiniz