



Mat. – Nr. – Konstante
3740


Gebrauchsanweisung
59 1117

- 1) 17 1312
2) 41 8169
3) 43 8726
4) 48 9131
V01
49 4164
V02,V03
5) 17 3865
6) 36 9905



Mat. - Nr. - Konstante
3740

- 1) 17 3883
- 2) 42 1330
- 3) 49 0671
- 4) 49 1361
- 5) 49 0670
- 6) 49 0669



Pos.	V01,V02	V03	
	Danfoss	Aspera	
	NLE15KTK2	NBM1119Y	
1	14 2207	14 3989	
2	42 0376		
3	35 4583		
4	16 3427		
5	49 1201	49 1138	
6	17 1318		
7	17 1519		
8	18 1014		
9	16 5570	42 5966	
10			
11			
12			

TECHNISCHE DATEN/TECHNICAL DATA/TEKNIK BİLGİLER				
	V01,V02	V03		
Verdichter/Compressor/Kompresör Typ/Type/Tip Förderleistung/Delivery/Verim/h Anlaufstrom/Starting current/Giris akimi Widerstand/Resistance/Rezistans Ha/ Hi/aux.	Danfoss NLE15KTK2 8 A Ω	Aspera NBM1119Y		
Temp. Regler/Thermostat/Termostat Typ/Type/Tip Reglerstellung/Position/Termostat pozisyonu Schaltwerte/Actma kapama degerleri Valeurs de commutation/Termostat degeri (...abtaven' od)	Elektronisch ..ein/acma °C ..aus"/kapama ..alarm'			
Füllmenge/Fill. quantity/ Dolum miktarı	R600	g	60	
Anschlusswert/Comm. load/Giris gucu	W	215		
Heizung/Heater/Rezistans Widerstand/Resistance/Direnc Leistung/Power/Guc	Ω W	Verdampfer 267	Ablaufrinne 81	Klappe 4
Ventilador/Blower/Vantilatör Widerstand/Resistance/Rezistans	Ω			
Magnetventil/Magnetic valve/Manyetik valf Widerstand/Resistance/Rezistans Spannung/Voltage/Gerilim	Ω V			
Temp. Regler/Thermostat/Termostat				

* Siehe Typenschild/Mamul etiketine bakiniz