






Gebrauchsanweisung
58 7171

- 1) 17 1312
- 2) 42 1516
- 3) 36 9815
- V01,V02,V03,V04
- V05,V06
- 43 8726
- V07
- 4) 48 9131
- 5) 16 5552
- 6) 36 9905
- 7) 41 8128
- 8) 36 6902
- V01,V02,V03,V04
- V05,V06
- 9) 48 8433
- V01,V02,V03
- 49 1665
- V04,V05,V06,V07
- 10) 36 3157
- V01,V02,V03,V04
- 43 7165
- V05,V06,V07
- 11) 36 6309
- V01,V02,V03,V04
- 43 7166
- V05,V06,V07
- 12) 36 9816
- V01,V02,V03,V04
- V05,V06



- 1) 49 0669
- 2) 49 0670
- 3) 43 4572
- 4) 16 5557
- 5) 49 1367
- 6) 49 0671
- 7) 47 0830
- 8) 06 0083
- 9) 18 8194
- 10) 18 8188



	V01,V02	V03V04,V05	V06
Pos.	Danfoss	Danfoss	
	NLE15KTK	NLE15KTK2	
1	14 2175	14 2207	
2	17 4093		
3	35 4583		
4	16 3427		
5	49 1201		
6	17 1318		
7	17 1519		
8	18 1014		
9			
10			
11			
12			

TECHNISCHE DATEN/TECHNICAL DATA/TEKNIK BİLGİLER			
	V01,V02	V03	
Verdichter/Compressor/Kompresör	Danfoss	Danfoss	
Typ/Type/Tip	NLE15KTK	NLE15KTK2	
Förderleistung/Delivery/Verim/h			
Anlaufstrom/Starting current/Giris akimi	8		
Widerstand/Resistance/Rezistans Ha/			
Hi/aux.			
Temp.Reyler/Thermostat/Termostat	Elektronisch		
Typ/Type/Tip			
Reglerstellung/Position/Termostat pozisyonu			
Schaltwerte/Actua kapama degerleri	..ein/acma °C		
Valeurs de commutation/Termostat degeri	..aus"/kapama		
(..abtaven' od)	..alarm'		
Füllmenge/Fill. quantily/ Dolum miktari	R600a	60	
	g		
Anschlusswert/Comm. load/Giris gucu	W	215	
Heizung/Heater/Rezistans	Verdampfer	Ablaufrinne	Klappe
Widerstand/Resistance/Direnc	Ω		
Leistung/Power/Guc	W	267	81
			4
Ventilador/Blower/Vantilatör			
Widerstand/Resistance/Rezistans	Ω		
Magnetventil/Magnetic valve/Manyetik valf			
Widerstand/Resistance/Rezistans	Ω		
Spannung/Voltage/Gerilim	V		
Temp.Reyler/Thermostat/Termostat			

* Siehe Typenschild/Mamul etiketine bakiniz