





Mat. – Nr. – Konstante
3740
Gebrauchsanweisung
58 9014 (dk)
58 9015 (no)
58 9016 (sv)
58 9017 (fi)

Montageanweisung
58 8262
(de,en,fr,it,nl,da,sv,no
fi,es,pt,el,cs,pl,tr,ru)


Zubehoer:
HEZ331000
Backblech emailiert
HEZ331010
Backblech Antihalt
HEZ332000
Universalpfanne
HEZ332010
Universalpfanne
Antihalt
HEZ333000
Profipfanne
HEZ333001
Deckel f. Profipfanne
HEZ334000
Kombirost
HEZ324000
Einlegerost
HEZ325000
Grillblech 2-teilig
HEZ336000
Glaspfanne

1) 01 4254





 Mat. - Nr. - Konstante
 3740

 Zubehoer:
 HEZ6001
 Backform
 Auslaufsicher
 HEZ317000
 Pizzaform
 HMZ21GB
 Glasbraeter
 HEZ6000
 Metallbraeter
 HEZ338200
 Teleskopauszug
 2-fach
 HEZ338300
 Teleskopauszug
 3-fach
 HEZ338305
 Teleskop-Vollauszug
 3-fach
 Ecolyse-Set
 HEZ329020




Mat. – Nr. – Konstante
3740

1) 06 8492




Mat. – Nr. – Konstante
3740

1) 42 0735



Mat. – Nr. – Konstante
3740



Mat. – Nr. – Konstante
3740