




Gebrauchsanweisung

58 7334

(el,en)

1) 17 2762

2) 17 2579


3) 41 8128


4) 18 4027


5) 06 0087

6) 06 0086

7) 42 3890







TECHNISCHE DATEN/TECHNICAL DATA/DONNEES TECHNIQUES/DATOS TECNICOS			
Verdichter/Compressor/Compresseur/Compresor	ASPERA		
Typ/Type/Tipo	NBT 1118Y		
Förderleistung/Delivery/Debit/Aspiración l/h	2574		
Anlaufstrom/Starting current/Cour.démarrage/Int.arranque A	–		
Widerstand/Resistance/Resistencia. Ha/main/prin. Ohm	11.0		
Hi/aux.	16.4		
Klappe Therm./Thermostat/Termostat			
Typ/Type/Tipo			
Reglerstellung/Position/Conexión			
Schaltwerte/Switching values/	..ein/conex.°C		
Valeurs de commutation/Desconex.	..aus"/descon.		
(..abtaven' od)	..alarm'		
Füllmenge/Fill. quantity/Charge/Carga R600	g	45	
Anschlusswert/Comm. load/Puiss. Connect./Potenc.	W	150	
Heizung/Heater/Chaufrage/Resistenc.descong.	Verdampfer	Ablaufrinne	Luftkanal
Widerstand/Resistance/Resistencia	KW	0.38	1.4
Leistung/Power/Puissance/Potencia	W	145/230	37.5/230
Ventilator/Blower/Ventilateur/Ventilador	Verdichter	Verdampfer	
Widerstand/Resistance/Resistencia	KW	0.61	0.41