




Gebrauchsanweisung
58 4386 (de)

Aufstellanweisung
58 4339 (de)

Programmtabelle
52 6933 (de)


1) Blende kompl.
36 0024 (de) V01
35 9756 (de) V02
36 0138 (de) V03


Zubehör:

Bodenbefestigung
WX9756

Entkalker
46 0038

1) 2 x pro Gerät





- 1) 26 3372
- 2) 26 3373
- 3) 16 5983
- 4) 26 3395
- 5) 16 5984
- 6) 48 0138
- kompl.
- 8) 16 5978

