







 15 6810  
 V04,V05  
 15 7324  
 V06

 15 6809  
 V04,V05  
 15 7402  
 V06


32 1337


 15 6808  
 V04  
 15 6811  
 V05  
 15 6807  
 V06

 Gebrauchsanweisung  
 51 8720  
 (D,E,F,GB,NL,I)  
 Kochbuch  
 52 0279  
 (D)

Zubehör:

 GE010-010  
 Gareinsatz ungelocht

 GE010-020  
 Gareinsatz gelocht

 FK022-000  
 Nudelkorb

 VV340-000  
 Verbindungsleiste für  
 Variogeräte

 VD050-010  
 Abdeckung Edelstahl

 AG050-000  
 Ablauf-Set