








- 1) 35 4164
- 2) 17 1321
- 3) 35 4166
- 4) 35 4167
V01
35 7912
V02
- 5) 35 4161
V01
35 7913
V02



Pos.	Danfoss		
	NL9FT		
1	14 1811		
2	16 5570		
3	16 3427		
4	35 4158		
5	17 1318		
6	26 5327		
7	17 1519		
8			
9			
10			
11			
12			

TECHNISCHE DATEN/TECHNICAL DATA/TEKNIK BILGILER			
Verdichter/Compressor/Kompresör	Danfoss		
Typ/Type/Tip	NL9FT		
Förderleistung/Delivery/Verim/h			
Anlaufstrom/Starting current/Giris akimi	A	12.8	
Widerstand/Resistance/Rezistans Ha/	Ohm	8.9	
Hi/aux.		12	
Temp.Reyler/Thermostat/Termostat	K59/P6834		
Typ/Type/Tip			
Reglerstellung/Position/Termostat pozisyonu			
Schaltwerte/Actua kapama degerleri	..ein/acma °C	+3.5 +3.5	
Valeurs de commutation/Termostat degeri	..aus"/kapama	-31 -20	
(..abtaven' od)	..alarm'		
Füllmenge/Fill. quantity/ Dolum miktari	R134a	g	*
Anschlusswert/Comm. load/Giris gucu	W	*	
Heizung/Heater/Rezistans			
Widerstand/Resistance/Direnc	Ohm		
Leistung/Power/Guc	W		
Ventilador/Blower/Vantilatör			
Widerstand/Resistance/Rezistans	Ohm		
Magnetventil/Magnetic valve/Manyetik valf			
Widerstand/Resistance/Rezistans	Ohm		
Spannung/Voltage/Gerilim	V		
Temp.Reyler/Thermostat/Termostat			

* Siehe Typenschild/Mamul etiketine bakiniz