


**BOSCH**

HMG8324/01-V01, weiß
 HMG8324FB/01-V02, weiß
 HMG8324NL/01-V03, weiß
 HMG8324GB/01-V04, weiß

HERDE
 Mikrowellenherde



Mat. – Nr. – Konstante
 3740

Gebrauchsanweisung
 51 7123
 (D, F, GB, I, NL, E)
 V01, V02, V03
 51 7143
 (GB, 10 A)
 V04

Kochbuch:
 51 5732
 (D)
 51 5859
 (NL)
 51 5858
 (F)
 51 6251
 (GB)

Zubehör:

Glaspfanne
 HMZ 10GP

Alu-Backblech
 HMZ 19BB

Universalpfanne
 HMZ 8605

Einbaurahmen
 HMZ 8022
 Abdeckplatte
 HMZ 8720

1) 15 0339




BOSCH

HMG8324/01-V01, weiß
HMG8324FB/01-V02, weiß
HMG8324NL/01-V03, weiß
HMG8324GB/01-V04, weiß

HERDE
Mikrowellenherde


Mat. – Nr. – Konstante
3740



**BOSCH**

HMG8324/01-V01, weiß
 HMG8324FB/01-V02, weiß
 HMG8324NL/01-V03, weiß
 HMG8324GB/01-V04, weiß

HERDE
 Mikrowellenherde



Mat. – Nr. – Konstante
 3740

- 1) 11 4538
Backblech
- 2) 11 4539
- 3) 27 3844
Universalpfanne
- 4) 03 2778
- 5) 27 1244
V01,V02,V03
27 1621
V04

02 8732
Anschlag-Backblech

**BOSCH**

HMG8324/01-V01, weiß
HMG8324FB/01-V02, weiß
HMG8324NL/01-V03, weiß
HMG8324GB/01-V04, weiß

HERDE
Mikrowellenherde

Mat. - Nr. - Konstante
3740

