




Gebrauchsanweisung
 52 8220
 (de,fr,nl,it)

Montageanleitung
 52 3265
 (de,fr,nl,it)

Kochbuch
 51 8368

1) 02 5876

Zubehör:


Back- u. Bratrost-
 engmasching
 Z1440X0

Back- u. Bratrost
 gekröpft
 Z1430X0


Backblech Alu
 Z1330X0

Backblech Email
 Z1340X0

Universalpfanne u.
 Bratrost
 Z1230X0



- 1) 18 2669
 V01
 18 2673
 V02
 18 2678
 V03
 18 2682
 V04
 2) 18 2668
 V01
 18 2672
 V02
 18 2677
 V03
 18 2681
 V04



- 1) 17 2765
- 2) 17 2646
- 3) 18 2612
- V01, V02
- 18 2427
- V03, V04
- 4) 18 2650
- V01
- 18 2676
- V02
- 18 2654
- V03
- 18 2658
- V04
- 5) 36 1653
- V01
- 36 1672
- V02
- 36 1657
- V03
- 36 1662
- V04

- 36 1654
- V01
- 36 1673
- V02
- 36 1659
- V03
- 36 1663
- V04

