






Libro de instrucciones
51 6523
(es,pt,it,fr,en)





Pos.	Necchi	Zanusi		
	ESM9	E88601		
1	14 0784	14 0784		
2	16 2827	16 2828		
3	16 2825	16 2826		
4/5	16 2829	16 2830		
5				
6				
7				
8	35 0445	35 0445		
9	15 4861	15 5001		
10				
11	26 1965	26 1965		
12				
13				

TECHNISCHE DATEN/TECHNICAL DATA/DONNEES TECHNIQUES/DATOS TECNICOS				
Verdichter/Compressor/Compresseur/Compresor Typ/Type/Tipo Förderleistung/Delivery/Debit/Aspiración l/h Anlaufstrom/Starting current/Cour.démarrage/Int.arranq. A Widerstand/Resistance/Resistencia. Ha/main/prin. Ohm Hi/aux.	Necchi ESM9	Zanusi E88601		
Temp.Reyler/Thermostat/Termostato Typ/Type/Tipo Reglerstellung/Position/Conexión Schaltwerte/Switching values/ ..ein/conex.°C Valeurs de commutation/Desconex. ..aus"/descon. (..abtaven' od) ..alarm'	RANCO F59L1160 MIN. MAX. +4 — -11 -30			
Füllmenge/Fill. quantity/Charge/Carga R12 g	*	*		
Anschlusswert/Comm. load/Puiss. Connect./Potenc. W	*	*		
Heizung/Heater/Chauflage/Resistenc.descong. Widerstand/Resistance/Resistencia Ohm Leistung/Power/Puissance/Potencia W				
Ventilador/Blower/Ventilateur/Ventilador Widerstand/Resistance/Resistencia Ohm				
Magnetventil/Magnetic valve/Electrovanne/Electrovalvula Widerstand/Resistance/Resistencia Ohm Spannung/Voltage/Tension/Tensión V				
Temp.Reyler/Thermostat/Termostato ambiente para ventilador refrigerador				

* Siehe Typenschild / See identification plate / Voir plaquette de caractéristiques / Ver plaqueta de características