





Gebrauchsanweisung
 58 4546
 (de,fr,nl,it)

Montageanleitung
 51 7991
 (de,en,fr,nl,it,es,pt,el)


Kochbuch
 58 3979

Zubehör:


Back- u. Bratrost-
 engmasching
 Z1440X0
 Back- u. Bratrost
 gekröpft
 Z1430X0
 Backblech Alu
 Z1330X0
 Backblech Email
 Z1340X2
 Universalpfanne u.
 Bratrost
 Z1230X2



1) 18 2438
2) 18 2431



- 1) 15 4762
- 2) 17 2765
- 3) 18 2427
- 4) 18 2428



1) 41 8562