





Gebrauchsanweisung
58 3978
(de,fr,nl,it)

Montageanleitung
52 3265
(de,fr,nl,it)


Kochbuch
58 3979

Zubehör:


Back- u. Bratrost-
engmasching
Z1440X0
Back- u. Bratrost
gekröpft
Z1430X0
Backblech Alu
Z1330X0
Backblech Email
Z1340X2
Universalpfanne u.
Bratrost
Z1230X2



- 1) 41 8407
- 2) 41 8402



- 1) 17 2765
- 2) 17 2646
- 3) 18 2612
- 4) 41 8432



1) 16 0916