




Gebrauchsanweisung

58 1593 (de)

58 1594 (en)

58 1595 (nl)

58 1596 (fr)

58 1597 (da)

Zubehör:

Universalpfanne
HZ 23300

Kombirost
HZ23400

Backblech Alu
HZ 21000


Glasbräter
HZ 9150

Grillblech


HZ22500


Backblech emailliert
HZ23100


1) 01 4254



1) Befestigungssatz
18 4210







- 1) 29 7213
Set
- 2) 16 3067
Set

