




Gebrauchsanweisung

52 0710 (D)	52 3063 (RU)
52 0983 (NL)	52 0973 (DK)
52 0984 (GB)	52 0979 (F)
52 0980 (I)	52 0970 (S)
52 0971 (N)	52 0972 (SF)

Aufstellanweisung

52 0502 (D)	52 0439 (SF,S,N,DK)
52 0492 (D,F,I)	52 0493 (NL,F,GB)

Programmtabelle



52 0711 (D)	52 0974 (S)
52 0975 (N)	52 0976 (SF)
52 0977 (DK)	52 0981 (F)
52 0982 (I)	52 0985 (NL)
52 0986 (GB)	52 3064 (RU)


1) Blende komplett

35 0410
 V01
 29 8575
 V02,V03,V04

2) 26 4084 (D)V02	26 4082 (F)
26 4083 (I)	26 4081 (S)
26 4078 (DK)	26 4079 (N)
26 4080 (SF)	26 4092 (NL)
26 4091 (GB)	
48 0688 (E)	

Kabelbaum:
 16 7633
 (N7 – NTC –
 Aqua Sensor)
 26 3248
 (N6 – Motor)
 26 3249
 (N1 – N7)





1) 23 3134
Dämmattenset
20 4859
mitbestellen

Zubehör:


Verbindungssatz für Wasch/Trockensäulen WZ20170

Verlängerung
Arbeitsplatte
WZ10040

Unterbauszubehör
WZ10090

Bodenbefestigung
WX9756

AQ-Stop-Ver-
längerung
WZ10130



1) Kabelbaum
N7-NTC-
Aqua Sensor
16 7633

