




Mat. – Nr. – Konstante
3740


Gebrauchsanweisung
58 8347 (de)

Montageanweisung
58 8262
(de,en,fr,it,nl,da,sv,no
fi,es,pt,el,cs,pl,tr,ru)

Zubehoer:
HEZ331000
Backblech emailliert
HEZ331010
Backblech Antihalt
HEZ332000
Universalpfanne
HEZ332010
Universalpfanne
Antihalt
HEZ333000
Profipfanne
HEZ333001
Deckel f. Profipfanne
HEZ334000
Kombirost
HEZ324000
Einlegerost
HEZ325000
Grillblech 2-teilig
HEZ336000
Glaspfanne


1) 01 4254
2) 02 0943






Mat. – Nr. – Konstante
3740

Zubehoer:
HEZ6001
Backform
Auslaufsicher
HEZ317000
Pizzaform
HMZ21GB
Glasbraeter
HEZ6000
Metallbraeter




Mat. – Nr. – Konstante
3740
1) 06 8492




Mat. – Nr. – Konstante
3740

1) 42 0735



Mat. – Nr. – Konstante
3740



Mat. – Nr. – Konstante
3740

1) 47 2958
Set