


**BOSCH**

WFF 1600 – WFF1600II/09–V01
 WFF 1600 – WFF1600II/11–V02
 WFF 1600 – WFF1600FF/11–V03

WASCHGERÄTE
 Waschvollautomaten



Mat. – Nr. – Konstante
 3740

Gebrauchsanweisung

51 7982
 (D,E,I,P)
 51 8101
 (D,F,I)

Aufstellanweisung

51 7986
 (I,P,E)
 51 8059
 (D,F,I)

Programmtabelle

51 7984
 (I)
 51 8021
 (F)

1) Blende
 29 9029
 (I)
 29 9030
 (F)

**BOSCH**

WFF 1600 – WFF1600II/09–V01
 WFF 1600 – WFF1600II/11–V02
 WFF 1600 – WFF1600FF/11–V03

WASCHGERÄTE
 Waschvollautomaten

20 4245
 Unterbauabdeckung

Ident – Nummern – Konstante
 3740

1) 29 7299
 Set

Zubehör:


Verbindungssatz für
 Wasch/Trockensäule
 WTZ1120


Verlängerung
 Arbeitsplatte
 WMZ2320

Unterbaubehör
 WMZ2340

Bodenbefestigung
 WMZ2200

Anschlußgarnitur
 für Kaltwasser 2,5 m
 WMZ2380





**BOSCH**

WFF 1600 – WFF1600II/09–V01
 WFF 1600 – WFF1600II/11–V02
 WFF 1600 – WFF1600FF/11–V03

WASCHGERÄTE
 Waschvollautomaten

Ident – Nummern – Konstante
 3740

