




Mat. – Nr. – Konstante
3740

Gebrauchsanweisung

51 7301

(D,GB,F,I,NL,E)

51 7308

(D)

Kurzanleitung

51 7307

(D)

Montageanleitung

51 6089

(D,GB,F,I,NL)

Kochbuch

51 5732

(D)

Aufkleber Programm-
tabelle

51 6344

(D,GB,F,I,E,N)

Zubehör:

Alu-Backblech


HMZ19BB

Glaspfanne

HMZ10GP


Glasbräter

HMZ21 GB



Mat. – Nr. – Konstante
3740


- 1) 03 0671
2) 03 0813
Arretierstift




Mat. – Nr. – Konstante
3740

- 1) 11 4538
Backblech
- 02 8732
Anschlag-Backblech
- 2) 11 4539
- 3) 11 4537
Glasschale
- 5) 23 2269
- 6) 09 2677
kompl.

Mat. – Nr. – Konstante
3740





Mat. – Nr. – Konstante
3740

1) 06 6979
Set