





Gebrauchsanweisung
51 9782 52 3528
(s) V01 (dk) V01
58 0494 58 0495
(fi) V01 (no) V01
51 9614
(gb) V02

Aufstellanweisung
52 3051 52 3017
(S) V01 (dk) V01
52 3018 58 0493
(fi) V01 (no) V01
51 8039
(gb) V02

Programmtabelle
51 9932 51 9783
(S) V01 (dk) V01
51 9934 58 0496
(fi) V01 (no) V01
51 9614
(gb) V02

1) Blende kompl.
29 6671
Blendeneinlage 2)
mitbestellen



Unterbauabdeckung
20 4245

Zubehör:

Verlängerung für
Arbeitsplatten
WZ 10040
weiß

Unterbaubehör
WZ 10090/01

Bodenbefestigung
WX 9756

Höhenanpassung 91 cm
WZ 10100

