
BATTERY CHARGE GROUND
TERMINAL BLOCK
STARTING RELAY COIL
GROUND CASE
BATTERY CHARGE
OIL ALERT
ENGINE COIL
CHOKE
"+" BATTERY
MAIN SWITCH
GROUND CASE
LOCK OFF
INTERNAL CONTROL PANEL
GROUND TERMINAL BLOCK
INTERNAL CONTROL PANEL
STARTING RELAY COIL
MAIN SWITCH
FUEL RESERVE TERMINAL BLOCK
GROUND CASE
STATOR
INVERTER
INTERNAL CONTROL PANEL
STARTER MOTOR
STARTING RELAY SWITCH
MAIN SWITCH
INTERNAL CONTROL PANEL
"+" BATTERY
STARTING RELAY SWITCH
ENGINE SUPPORT METAL PLATE
GROUND CASE

600148
CAPACITOR
YELLOW CABLE OIL SENSOR
INTERNAL CONTROL PANEL

(P2TEC29EW)